Thank you for your purchase on W2COMP! Here we would like to teach you how to upgrade the firmware of Android Tablet PC based on All Winner A10 CPU.

Updated on 30-May-2012, the models of All Winner A10 we have:

1. **Ainol Novo7 Aurora**
2. **Ainol Novo7 Advanced II**
3. **Ampe A90**
4. **Ampe A10**
5. **Eken A90**
6. **Eken T01**
7. **Ployer Momo9**

Precautions:

A power failure during the firmware writing operation may disable the tablet PC.

*** Use a fully charged Battery or dedicated AC Adapter for the firmware update.**

* Do not shut off the power during the firmware writing operation.

Please download the Livesuitpack, Livesuit USB driver and the firmware which you need from our website:
http://www.w2comp.com/news.asp?menuid=11248&supmenuid=11146

1. **Please unzip "Livesuitpack_version_1.09.rar", password is: w2comp.com , as below:**

LiveSuitPack_version_1.09	2012/2/24 9:27	WinRAR 压缩文件	15,458 KB
LiveSuitPack_version_1.09	2012/3/9 1:17	文件夹	

2. **Open the unzipped file " Livesuitpack_version_1.09".   You will see " livesuitpack_version_1.09_20111101",**

LiveSuit.lan	2012/2/24 9:27	LAN 文件	9 KB
LiveSuitCN	2012/2/24 9:27	编译的 HTML 帮…	1,896 KB
LiveSuitEN	2012/2/24 9:27	编译的 HTML 帮…	1,896 KB
LiveSuitPack_version_1.09_20111101	2011/11/1 16:17	应用程序	12,116 KB
LiveSuitTW	2012/2/24 9:27	编译的 HTML 帮…	1,896 KB
Phoenix_Elf.dll	2012/2/24 9:27	应用程序扩展	24 KB

3. **Copy it to another empty file:**

| 名称	修改日期	类型	大小
LiveSuitPack_version_1.09_20111101	2011/11/1 16:17	应用程序	12,116 KB

4.   Double click the file, you will required to make a slection on language first, just choose "English":


5.   After you make the language selection, the tool will be installed as below:

6.   Double click the "LiveSuit" icon, you will see as below. It proof that your computer has found the usb driver. Please choose "no":

7.   Click " SelectImg" and select the firmware which you want to installed to your tablet PC.


8.   Then, you can connect one top of the cable to your computer.

8.1 And, please press and hold your finger on the volume button, please do not loose until the upgrade started

8.2 Connect the another top of cable to your device. Please note that the finger on the volume button still press there

8.3 Please use your another finger to press the power button four or five times until below picture appear in your computer , please choose "Yes" to format the device. Then the upgrade started.

9. **After the upgrade completed, you can move the device from the computer directly.**